



2QTH PRO NEXT-GEN 2
COMMERCIAL ULTRASONIC
OPERATING PROCEDURES & MANUAL

GEMORO®
POWERFUL ULTRASONICS

Congratulations on your purchase of a **GEMORO** Powerful Ultrasonics, the most trusted name in ultrasonic cleaning equipment for the professional. You've made a smart choice, as your new **GEMORO** 2QTH PRO ultrasonic is the culmination of decades of experience and technological breakthroughs in ultrasonic cleaning technology. **GEMORO's** proprietary TURBO SWEEP TECHNOLOGY provides the most efficient and fastest cleaning possible. The engineers at **GEMORO** have designed the ultimate ultrasonic cleaner, with amazing power, workhorse reliability and unequaled performance that is built to last for years.

The Five Basic Steps

- STEP 1** Add an appropriate mixture of tap water to the ultrasonic tank along with one of the specially formulated, super concentrated **GEMORO** ultrasonic cleaning solutions referenced in the back section of this manual for the ultimate in cleaning and brightening of your jewelry. Fill it approximately to 1/2 inch or 13mm from the rim of the tank. NEVER operate the ultrasonic when empty or damage may occur.
- STEP 2** Connect to an electrical outlet with the appropriate voltage of 110-120V. Flip the power switch on the rear of the ultrasonic ON.
- STEP 3** Place the jewelry to be cleaned in the supplied basket or ring rack and submerge it in the tank. NEVER place items you wish to clean on the tank bottom or damage to the transducers; stainless steel tank and/or jewelry may occur.
- STEP 4** Set the thermostat to the desired temperature.
- STEP 5** Set the timer to the appropriate length of cleaning time required, which is dependent on the extent of the dirt and grime present, and the amount of jewelry being cleaned.

Product Reference Guide

- 1. Stainless Steel Handles
- 2. Heat Dispersion Vents
- 3. Heater LED Temperature Level Indicator
- 4. Thermostatically Controlled Heater Knob
- 5. Timer LED Indicator
- 6. 0-60 Minute Timer Knob
- 7. Power Entry Connector & Fuse Compartment
- 8. Power ON/OFF Rocker Switch
- 9. Product Information Sticker
- 10. Rubber Feet
- 11. Stainless Steel Cover
- 12. Stainless Steel Basket
- 13. Stainless Steel Soft Grip Tweezers
- 14. Stainless Steel Ring Rack



Safety Symbols

This manual is marked with the universal **HAZARD** ⚠ symbol to alert you of specific areas within the manual that the operator must carefully read in advance of using to prevent damage to the ultrasonic and/or injury to the operator.

Electrical Power Installation

Your **GEMORO** Powerful Ultrasonics unit has been factory preset for use with 110-120 volt operation. The ultrasonic unit is supplied with a three-prong electrical plug. ⚠ **DO NOT remove the grounding prong from this connector, as it may cause an electrical shock!** ⚠ Plug into an electrical outlet that has a ground fault protection device (GFI, GFCI) for optimum safe operation. ⚠ When possible, plug the ultrasonic into a separate dedicated circuit/outlet. Some electrical circuits/outlets will not supply enough power to properly run more than one electrical appliance, especially if large appliances such as steamers, polishers, dust collectors, etc. are being operated at the same time. Reduction of cavitation in your ultrasonic could be the result of not enough power to your unit.

Water Solution Mixture in Ultrasonic Tank

To maximize the cleaning process, the proper cleaning solution must be added to the water in the ultrasonic tank. We recommend using any of the specially formulated, super concentrated **GEMORO** cleaning solutions referenced in the back section of this manual for the ultimate in cleaning and brightening of your jewelry. ⚠ **WARNING: Do not use flammable solutions (that contain alcohol, etc.) or acid-based solutions (such as Drano, etc.) or ammonia-based solutions in your ultrasonic.** ⚠ **Under any circumstances, NEVER TURN YOUR ULTRASONIC ON WHEN THE TANK IS EMPTY.** Place the water/cleaning solution mixture in the tank while filling the tank to approximately one inch from the tank's rim and maintain it at that level.

Submerge the jewelry to be cleaned in the tank no less than 1/2 inch or 13mm below the solution surface to obtain optimal cleaning and be certain not to place jewelry or anything being cleaned on the bottom of the tank, as it may damage the transducers, stainless steel tank and/or jewelry, while voiding the warranty. ⚠ Be careful not to clean heavily included stones (such as emeralds), because the ultrasonic sound waves and/or heat may crack the stone. ⚠ Be certain not to clean soft, water porous stones (such as pearls, opals, coral, turquoise, etc.) as they too may be damaged. Be certain not to clean any oil treated stones in any cleaning solution which may contain a degreasing agent, as the solution may damage the stone and/or revert the stone back to its untreated condition. Typically, items such as gold, silver, platinum, diamonds, rubies, sapphires etc. are safe for ultrasonic cleaning. **For more specific information on which stones are suitable for cleaning in an ultrasonic please refer to Page 11 of this manual and we also suggest you consult with a gemologist or the GIA (Gemological Institute of America). Do not submerge watches in any ultrasonic, as damage to the watch may occur.** However, it may be safe to carefully submerge the metal watchband into the tank for cleaning while being certain not to submerge the head of the watch at any time. At your own risk, before attempting this, always be certain the watches stem is fully inserted and/or tightened/screwed all the way in.

Flip the Power Switch, then Turn Ultrasonic ON by Turning the Timer Knob Clockwise & Turn Heater ON to Desired Temperature

IMPORTANT FEATURE: For prolonged heater life, your ultrasonic has an AUTO-OFF function that turns the heater off after 4 hours of use. Simply turn the heater knob off and then back on to reengage the heater.

Flip the power switch located on the rear of the machine to power it up. Then turn the timer and heater knobs to the desired position. Depending on the load in the tank and how dirty the jewelry is that you are cleaning will determine the length of cleaning time required. **NEVER attempt to block the timer for continuous usage, as the GEMORO Powerful Ultrasonics unit has been designed to perform for many years and to do so would potentially damage the unit or shorten its life span, as well as void the warranty.** Heated water/solution will enhance the ultrasonics cleaning ability. By turning the thermostat knob to a specified temperature, the unit will quickly heat up to the temperature range selected. All the specially formulated **GEMORO** concentrated cleaning solutions are designed to work best with a heated ultrasonic cleaner. These solutions allow the dirt, grime, etc. to be broken down and loosened from the jewelry much faster than other traditional cleaning solutions.

NOTE: Optimal cleaning temperatures for ultrasonics ranges from 104°F to 140°F. Generally, the higher the temperature, the more effective cleaning will occur. However, after approximately 158°F, cavitation power begins to become diminished. Only use high temperatures if you desire more of a degreasing effect over cavitation power.

SAFETY FEATURE: For safety and additional prolonged heater life, the heater in your ultrasonic will automatically SHUT DOWN once it reaches 220° F. This temperature will typically be reached if the water level is too low due to evaporation. Immediately add water. After the temperature reduces, the heater will automatically begin operating again.

Turbo Sweep® Technology

GEMORO Sweep Frequency Technology has been recognized for decades as the most powerful ultrasonic cleaning system available. This powerful technology is very apparent and physically seen in the ultrasonic as significantly more aggressive ultrasonic cavitation within the ultrasonic tank. The result of this more powerful cavitation is faster, more efficient and effective cleaning in reduced time. (It should be noted that most of the ultrasonics produced by the various competitive ultrasonic manufacturers utilize the older non-sweep ultrasonic technology. This technology is noticeably visibly seen by their relatively flat, non-aggressive cavitation within the ultrasonic tank.) Amazingly enough, while sweep technology has been considered the best for cleaning, the engineers at **GEMORO** have since developed an even more powerful cleaning technology with its proprietary Turbo Sweep. The Turbo Sweep has twice the power of the competitive technology used by other ultrasonic manufacturers. The Turbo Sweep is optimal for the rapid cleaning and/or when cleaning the dirtiest of items. This even more powerful, remarkable cleaning technology is clearly visible in the ultrasonic tank with significantly greater and more aggressive cavitation. The result is the fastest, most efficient and effective cleaning available. Period.

⚠ IMPORTANT: BE CERTAIN TO ADD WATER AS IT EVAPORATES FROM THE TANK AND DO NOT LET THE WATER LEVEL FALL BELOW APPROXIMATELY 1 INCH OR 25MM FROM THE RIM. THIS WILL AVOID HARMFUL DAMAGE TO THE HEATING ELEMENT.

Sound Dampening Feature

Your **GEMORO 2QTH PRO** has a proprietary sound dampening insulation that significantly reduces the level of the inherent noise produced by the industrial strength **GEMORO** transducers and cavitation.

Typical Degassing Period for Solution

Degassing is the natural process of removing gasses from any tank solution being affected by ultrasonic sound waves. Degassing occurs whenever you first use your ultrasonic with fresh water/solution and will recur each time you add to or change your water/solution. Water that has not been degassed will cause the cavitation (action) of the ultrasonic to appear very slow or flat. Depending on the solution you are mixing with water in your unit, the degassing time with most ultrasonics may vary from around 5 to as much as 15 minutes depending upon factors such as temperature and soap content. The rule of thumb is that the thicker and slimier the solution, the less time the degassing process will take.

Exclusive Instantaneous Auto-Degassing System

Unlike traditional ultrasonics, **GEMORO Powerful Ultrasonics** feature a proprietary system which provides almost instantaneous degassing, which gives users the ability to not only clean better, but faster too.

Cavitation

Inertial cavitation occurs in the presence of an acoustic field. Microscopic gas bubbles which are generally present in a liquid, will be forced to oscillate due to an applied acoustic field. If the acoustic intensity is sufficiently high, the bubbles will first grow and then rapidly collapse or implode, at which point the gas within dissipates into the surrounding liquid via a rather violent mechanism. It then releases a significant amount of energy in the form of an acoustic shockwave and as visible light. At the point of total collapse, the temperature of the vapor within the bubble may be several thousand degrees Kelvin, and the pressure several hundred atmospheres. Ultrasonic cleaning baths efficiently utilize the inertial cavitation of microscopic gas bubbles for the cleaning of dirt from materials such as jewelry, instruments and parts etc.

When the cavitation bubbles collapse or implode, they focus liquid energy into very small volumes. Thereby, they create spots of high temperature and emit shockwaves which are the source of the noise typically heard with ultrasonic cleaners. Although the collapse of the bubbles is a relatively low energy event, it is highly localized and can over time erode metals, such as stainless-steel. The pitting seen in ultrasonic tanks caused by the collapse of bubbles produces great wear on the stainless-steel tanks in ultrasonics, as well as ultrasonic components. This can dramatically shorten the lifespan of an ultrasonic cleaner, especially its tank. Because of this reality, every ultrasonic tank will eventually fail due to erosion, and depending on the ultrasonics usage, the lifespan of the ultrasonic and tank will vary from ultrasonic to ultrasonic. Ultrasonics systems that are operated excessively simply reach the end of their lifetime sooner. In addition to the erosion caused by cavitation, the elevated bath temperatures from heavy or prolonged operation contributes dramatically to assisting with the speed in which erosion will naturally occur in this type environment. Further, with the understanding that acidic or caustic chemicals (as described and expressly warned against further in this document) will directly damage the tank causing quick erosion while voiding the ultrasonics warranty. It should be recognized that many buffing compounds like rouge contain abrasives that will also over time speed up the erosion process of the stainless-steel tank as well. With this in mind, and to slow down the process of erosion because of abrasives in the solution, it is highly recommended that users regularly change their dirty cleaning solution and clean out the tank daily.

Power Surge & Built-In Fuse Protection

GEMORO Powerful Ultrasonics feature protection for the electronics from the unlikely event of a power surge or short circuit. This could otherwise cause severe damage to the electronics within the ultrasonic. ⚠ In the event your ultrasonic shows no indication of power, you must first disconnect the power cord before attempting the basic service of fuse replacement. Then locate the external fuse holder that is conveniently located in the rear side of the ultrasonic housing, connected to the power-entry connector. With a small screwdriver, pull open the fuse drawer underneath the plug outlet on the power-entry connector. Carefully take out the fuse while noting its condition. A blackened glass window or broken fuse wire indicates that the fuse has blown. Replace it with a new fuse of the exact type and rating as indicated on the Unit Technical Specifications (located on Page 12). Once you have replaced the fuse, then plug-in the ultrasonic to its power receptacle and resume cleaning. ⚠ If the fuse fails again or the ultrasonic still will not function, this is an indication that a more serious problem exists and that the ultrasonic needs service by the factory.

Helpful Suggestions & Precautions

Please Follow Closely to Avoid Loss of Warranty Coverage!

-  Always disconnect power cord before performing any maintenance on the ultrasonic unit. Position the ultrasonic unit so that there is easy, unobstructed access to the power connection.
- Change your ultrasonics water or water/solution regularly and clean out the tank.
- Cover your tank with the supplied lid to avoid evaporation and reduce noise levels.
- Use any of the superior concentrated **GEMORO** cleaning solutions mixed with water for optimal cleaning. solutions mixed with water for optimal cleaning.
-  Operate with the proper level of water/solution in tank.
-  Never put your fingers into an active, running ultrasonic tank, as repeated exposure to ultrasonic sound waves may be harmful, as well as a heated ultrasonic may burn you!
- Be certain not to allow any item being cleaned to rest on the bottom of the tank.
- Be certain not to allow the water/solution in the tank to drop below two inches from the bottom.
-  Be certain not to place flammable, acidic or ammoniated liquids in the tank, as they may ignite and/or cause damage to you or others. Further, it may cause damage to your ultrasonic which will void the warranty.
-  Do not install plug into an ungrounded electrical outlet.
- Do not attempt to block the timer for continuous usage. Units without a timer should not be used for long periods without an occasional 10 second break, as damage may occur and void the warranty.
- **Never operate the ultrasonic without water/solution in the tank.**
- For any problems or questions, please consult your supplier or contact **GEMORO at 800.527.0719 or 214.351.0380 or service@sykessler.com.**

Why Does the Ultrasonic Get So Hot?

 Occasionally users of ultrasonic cleaners become concerned because the temperature of their ultrasonic cleaning solution within the tank becomes very hot. This is typically only experienced by high volume users who operate the heated ultrasonic throughout the day. The principle of ultrasonic cleaning is to cavitate a liquid medium (typically water mixed with an ultrasonic cleaning solution). When this is done it creates tremendous shock waves caused by millions of microscopic vacuum cavities imploding within the solution inside of the tank.  These vacuum cavities build to tremendous pressures and temperatures (above 10,000 degrees Fahrenheit) that are instantaneously released into the solution upon implosion. The release of this energy causes the solution temperature to elevate.

By simply turning the ultrasonic cleaner ON and OFF will cause the solution temperatures in the tank to fluctuate—rising from the energy caused by the cavitation and falling from evaporative losses when the ultrasonic cleaner is OFF. The longer an ultrasonic cleaner is ON—the hotter the solution will become and the more intense the cavitation is—the faster the solution temperature will rise. In addition, when the heater is also left on a higher temperature, the heat even further intensifies.

There are several variables that affect the rate of temperature increase such as length of cleaning cycles, the tank load size of each cycle, the rate of heat loss and the length of time between cleaning cycles. Additionally, the performance of the ultrasonic cleaner itself plays a huge part in the rate of temperature increase—cavitation density and power levels.

GEMORO Powerful Ultrasonics, with their Turbo Sweep technology are considered the most powerful, best performing ultrasonic cleaners available as evidenced by their extremely aggressive cavitation or action seen on the surface of the ultrasonic solution. Ultrasonics that operate poorly or that are inferior by comparison will not heat up nearly as fast as high-performance ultrasonic cleaners like **GEMORO**. So, the better the ultrasonic performs—the hotter the bath will become. **CAUTION should always be used when operating an ultrasonic cleaner, as the solution does become hot and can cause injury to hands, etc. To protect from possible injury, protective gloves must always be worn.**

Things to Know in Order to Address the Concerned Cleaning Technician When They Ask, “Why Is the Ultrasonic Cleaner Getting So Hot?”

- Energy causes substances to rise in heat.
- Higher energy levels cause accelerated rise in temperature.
- Cavitation is energy.
- The principle of ultrasonic cleaning is to cavitate a liquid.
- Using an ultrasonic cleaner will cause the solution temperature to rise.
- An ultrasonic cleaner with high levels of cavitation will cause the solution temperature to rise at a faster rate than low level cavitation ultrasonics.
- **GEMORO** ultrasonic cleaning systems yield high powered, high-density cavitation through its proprietary Turbo Sweep technology.
- If your **GEMORO** ultrasonic is being used throughout the day, it is recommended to periodically turn OFF the heater to avoid over-use and to extend the life of the ultrasonics heating element. If the solution in the tank becomes excessively hot or reaches boiling point, this is an indication that the heat level must be reduced immediately as it is not designed to function in this environment.
-  Protective gloves should be worn to prevent injury.

NOTICE: The heater works independently from the cavitation functions. Leaving your thermostat knob at a high temperature, even when the unit is not producing cavitation, will result in the eventual evaporation of the water/solution within the tank. This could burn out the heating element within the ultrasonic. ALWAYS ADD MORE WATER AS IT EVAPORATES! If these instructions for overheating are not followed, you could damage your ultrasonic and void its warranty!

IMPORTANT FEATURE: For a prolonged heater life, your ultrasonic is equipped with an AUTO-OFF function that TURNS THE HEATER OFF AFTER 4 HOURS OF USE. Simply turn the heater knob off and then back on to reengage the heater.

Heater Auto-Off & Built-In Protection If Heater Is Accidentally Left On

To help safeguard your ultrasonic and prolong its life, an innovative new feature has been built-in to it that will automatically turn the heater function off if the water level gets too low and it overheats while reaching 220°F. This will help to prevent prematurely burning out the heating element in the event the water in the ultrasonic totally evaporates due to the heater accidentally being left on overnight. In the event the heater safeguard is activated, first fill the tank back up with water/solution. Then to reengage the heater, simply turn the heaters thermostat knob off and then back on again to the desired temperature.

Unit Technical Specifications:

Note: Power consumption is typical for a unit with heat ON and Turbo ON.

Model/ Item #	Tank Capacity	Line Voltage	Line Frequency	Power Consumption	Fuse Required
2QTH PRO	2 Quart (0.5 Gal.)	110/120v	40 kHz	125/150w	1 Amp, 250v 5mm diameter (Φ), 20 mm long
1732- HPD	<u>Overall Size:</u> 19cm x 17cm x 22cm <u>Tank Size:</u> 15cm x 14cm x 10cm Stainless steel lid, tweezers, ring rack and basket included.				

The Following List of Hazardous Chemicals Can Attack the Stainless-Steel Tank On Your GEMORO Powerful Ultrasonics Unit:

⚠ IMPORTANT! Do not use any of these hazardous chemicals in your ultrasonic or the warranty will be void! Please be advised that pin holes, rust, bluing of the metal and cracks appearing in this ultrasonic tank are caused by the use of hazardous chemicals such as acid, Drano, Mr. Clean, etc. Any ultrasonic tank returned for repair with these symptoms will not be repaired under warranty coverage.

Acetic Acid (70 + degrees F)	Freon
Acetol Chloride	Hydrobromic Acid
Acetol Bromide	Hydrochloric Acid
Aluminum Chloride	Hydrocyanic Acid
Aluminum Fluoride	Hydrofluoric Acid
Anhydrous Ammonia (70 + degrees F)	Hydrofluosilicic Acid
Aniline Hydrochloride	Iodine
Antimony	Ketones
Antimony Trichloride	Lactic Acid (70 + degrees F)
Benzene	Magnesium Chloride
Bromine	Mercuric Chloride
Calcium Hydroxide (50% + strength)	Methyl Alcohol
Carbon Disulphide	Muritic Acid
Carbon Tetrachloride	Oleic Acid
Chloroacetic Acid	Oxalic Acid (70 + degrees F)
Chloric Acid	Phosphoric Acid (70 + degrees F)
Chlorinated Water	Silver Bromide
Chromic Acid (70 + degrees F)	Silver Chloride
Citric Acid (70 + degrees F)	Sodium Hypochloride (5% +)
Copper Chloride	Stannic Chloride
Ethers	Stannous Chloride
Ethyl Bromide	Sulphur Chloride
Ethyl Chloride	Sulphuric Acid
Ethylene Dichloride	Sulphur Monochloride
Ferric Chloride	Sulphurous Acid
Ferrous Chloride	Trichloroacetic Acid
Fluorine	Zinc Chloride (70 + degrees F)

PRELIMINARY GUIDELINE FOR GEMSTONE CLEANING		
GEMSTONE	TOUGHNESS	ULTRASONIC
Alexandrite	excellent	usually
Amazonite	poor	never
Amber	poor	never
Amethyst	good	usually
Aquamarine	good	usually
Citrine	good	usually
Coral	fair	risky
Diamond	good	usually
Emerald	poor	never
Garnet	fair	usually
Lolite	fair	risky
Lapis Lazuli	fair	risky
Opal	fair	never
Pearl	good	never
Peridot	fair	risky
Ruby	excellent	usually
Sapphire	excellent	usually
Spinel	good	usually
Tanzanite	fair	never
Topaz	poor	never
Tourmaline	fair	risky
Turquoise	fair	never
Variscite	fair	never
Zircon	fair	risky



WARRANTY

2.5 /10 Year Limited Warranty

Important Notice - Premature Tank Erosion & Component Failure

Congratulations on your purchase of a **GEMORO** Powerful Ultrasonics, the best, most powerful and efficient ultrasonic cleaner available. Your complete ultrasonic is warranted for a period of two and one half (2.5) years, while the ultrasonics transducer is warranted for a period of ten (10) years from the date of purchase (as shown on the Warranty Registration Form and your purchasers invoice) from defects in manufacturing and workmanship when used in accordance with the **GEMORO** Powerful Ultrasonics Operating Procedure (with the exceptions as noted in this document*). www.sykessler.com/warranty-registration/ In the event your ultrasonic fails to perform to its specifications, please contact your supplier or **GEMORO** and make arrangements for it to be returned for service. It is always wise to save your original shipping container for transporting your ultrasonic safely, but if it is not available, please be certain to properly package and protect your ultrasonic during shipping. **If upon examination of the ultrasonic by the factory, the factory determines that the ultrasonic has been damaged due to misuse, this warranty is void.**

Please be aware that there are certain telltale signs of abuse, which will automatically void the warranty. Some signs of user abuse: 1. Holes in the tank. 2. Bluing of the metal. 3. Specific odors associated with acid and ammonia exposure. 4. Burn marks on the tank are signs that an inadequate amount of water has been used in the tank. 5. Pitting or marks on the tank bottom are indications of items being placed on the tank bottom.

This warranty is limited to only the cost of any parts, materials, and labor required while repairing the unit. In the rare case of an "out-of-box failure," immediately contact your supplier or **GEMORO**, as the unit may be returned for replacement.

In the event the owner has not registered their ultrasonic machine or provided a copy of their invoice for when they purchased their **GEMORO** Powerful Ultrasonic, warranty service will be determined by the serial number tracking system as interpreted by the factory. In the event the specific model of **GEMORO** Powerful Ultrasonic is no longer available or has been discontinued and warranty coverage is applicable, at the factory's sole discretion, an equivalent ultrasonic machine may be substituted in place of the defective/discontinued unit. The purchaser shall incur the cost for postage, insurance and handling for all warranty and non-warranty repairs. Warranty repairs and/or replacements will be shipped back to the customer FOB Destination to the location of the customer's choosing if within the continental United States. Non-warranty repairs and units coming from outside of the continental United States will be shipped back to the customer FOB Factory. Should the customer require the repair and/or replacement unit(s) to be shipped outside the continental United States, the customer will be required to pay any related shipping charges and any related taxes/duties for the respective destination country, regardless of whether it is a warranty or non-warranty claim.

All **GEMORO** ultrasonic units are pre-tested to help insure your receipt of a top quality ultrasonic. Pre-testing requires filling the ultrasonic with water and turning the heater on (if applicable). This action may leave a slightly visible ring or stain where the water level reached or where any water has touched as well as a discoloration on the bottom of the tank from testing the heater. This ring may show up on your unit anytime your water level gets below its normal full level. This ring or stain in many instances may be cleaned with many regular household cleaners or WD40 but can never be completely removed.

Please be certain to fill out the **GEMORO** Powerful Ultrasonics Warranty Registration Form online at www.gemoroproducts.com/warrantyregistration within 30 days of purchasing your ultrasonic to be eligible for warranty coverage. Without registering your ultrasonic as required, assuming the purchaser does not provide a copy of their invoice (bill of sale), it will automatically be warranted for a period not to exceed one year.

NOTE: If you have any questions concerning the operation of your ultrasonic, its warranty or would like to purchase a new ultrasonic, please contact your supplier or contact the factory at **214.351.0380** or **800.527.0719**, or EMAIL **service@sykessler.com** to locate an authorized **GEMORO** Powerful Ultrasonics dealer near you. To view the complete line of **GEMORO** Powerful Ultrasonics, cleaning solutions and other products, please visit our website at www.gemoroproducts.com.

GEMORO SUPER CONCENTRATE CLEANING SOLUTION

To obtain the best general cleaning results out of your ultrasonic, we have the solution: **GEMORO** Ultrasonic Cleaning Solution! Economical to use, it dilutes 40 to 1 for light cleaning, 20 to 1 for heavy cleaning. Our solution is recommended for removing dirt, grease, buffing compounds, rouge, tripoli and oxides. Also used for cleaning instruments, burs, metal parts, gold and fine jewelry. **GEMORO** Super Concentrated Cleaning Solution is great for ultrasonics, glass and general cleaning. Non-ammoniated, no color additives, super concentrated, biodegradable, non-toxic and non-flammable. Instructions for use are imprinted on each bottle in both English and Spanish.

1-QUART BOTTLE

Item #0901-N

Each quart makes up to 40 quarts
(Case quantity-12)

1-GALLON BOTTLE

Item #0902-N

Each gallon makes up to 40 gallons
(Case quantity-4)





10455 Olympic Drive, Dallas, Texas 75220 USA
800.527.0719 or 214.351.0380
gemoroproducts.com
sales@gemoroproducts.com
service@sykessler.com